# (108) (81) $\langle$ 71angle(61) (51) (02) **★**6" min.

## **KEY NOTES**

- (02) Structural Concrete Deck
- (19) Existing Wall Assembly
- 23 Approved Insulation
- (25) Compressible Insulation
- ⟨36⟩ Base Sheet Liner
- (38) Protection Sheet, Optional
- (39) Drainage Board with Fabric
- 41 Approved Primer
- 44 Tremseal D, Optional
- AlphaGuard MT/MTS Base Coat
- 61 AlphaGuard Glass Mat or Permafab
- (71) AlphaGuard MT/MTS Top Coat
- (81) Paver
- 82 Paver Pedestal
- (97) Wood Curb Assembly, Slope to One Side
- Sheet Metal Expansion Joint Cover

AlphaGuard MT/MTS Expansion Joint Detail, Direct to Concrete Detail 10081



# (108) (81) $\langle 72 \rangle$ (61) 52 (02) **★**6" min.

## **KEY NOTES**

- (02) Structural Concrete Deck
- (19) Existing Wall Assembly
- 23 Approved Insulation
- 25 Compressible Insulation
- (36) Base Sheet Liner
- (38) Protection Sheet, Optional
- Orainage Board with Fabric
- 41 Approved Primer
- 44 Tremseal D, Optional
- 52 AlphaGuard BIO Base Coat
- 61) AlphaGuard Glass Mat or Permafab
- $\langle 72 \rangle$  AlphaGuard BIO Top Coat
- (81) Paver
- 82 Paver Pedestal
- 97 Wood Curb Assembly, Slope to One Side
- Sheet Metal Expansion Joint Cover

AlphaGuard BIO Expansion Joint Detail, Direct to Concrete Detail 10082



# (108) (81) $\langle 73 \rangle$ (61) 53 (02) **★**6" min.

## **KEY NOTES**

- (02) Structural Concrete Deck
- (19) Existing Wall Assembly
- 23 Approved Insulation
- (25) Compressible Insulation
- ⟨36⟩ Base Sheet Liner
- (38) Protection Sheet, Optional
- (39) Drainage Board with Fabric
- 41 Approved Primer
- 44 Tremseal D, Optional
- (53) AlphaGuard Puma Base Coat
- 61 AlphaGuard Glass Mat or Permafab
- (73) AlphaGuard PUMA Top Coat
- (81) Paver
- 82 Paver Pedestal
- (97) Wood Curb Assembly, Slope to One Side
- Sheet Metal Expansion Joint Cover

AlphaGuard PUMA Expansion Joint Detail, Direct to Concrete Detail 10083

