

POWERply® Standard FR HW

A Fiberglass Reinforced, Granule Surfaced Torch Applied SBS Modified Bitumen Membrane

FEATURES

SBS Polymer Modified Bitumen

Fiberglass Reinforced

Torch Applied

Factory Applied Surfacing

BENEFITS

- Resists thermal shock and accommodates movement

- Dimensionally stable
- Non-rotting fabric

- Economical application method

- Saves jobsite labor

DESCRIPTION

POWERply® Standard FR HW (Heat Weld) is a fiberglass reinforced, SBS modified bitumen membrane. This membrane is furnished with a standard factory granule surfacing and a burn-off polyethylene sheet on the underside of the membrane. POWERply Standard FR HW is also asbestos free. POWERply Standard FR HW exceeds ASTM D 6163, Type I, Grade G.

BASIC USES

POWERply Standard FR HW is designed for applications in hot air heat welded (torch applied) multi-ply roof and flashing systems where a factory granule surfacing is desired. Refer to UL Roofing Materials and Systems Directory and/or FM Approvals RoofNav for applicable system configurations.

DIMENSIONS

POWERply Standard FR HW is a 4.2 mm (165 mil) thick membrane. Roll covers 95.8 sq. ft. (8.9m²) when applied, with roll dimensions of 39 3/8" x 32'10" (1m x 10.01m). Approximate roll weight is 106 lbs. (48 kg). Available in pallets only.

APPLICATION

General Application Data: The following application information is designed to serve as a general guide. Your local Tremco Representative will prepare detailed specifications based upon your roof's conditions.

Drainage: Ponding conditions are unacceptable and will adversely affect performance of any roofing system. If positive drainage does not exist, water removal must be facilitated by lowering drains, and/or installing additional drains, tapered insulation, or a Tremco approved light-weight cellular insulating concrete slope system.

Insulation: Insulation must be dry and kept dry. No more insulation shall be installed than can be covered that day.

Installation Procedures: According to job specifications, prepare the surface to be covered:

- Replace areas of wet insulation, deteriorated deck and wood components.
- Install roof insulation or nailed base sheet and multi-ply base ply system.

Application: Plan the placement of POWERply Standard FR HW to ensure that water flows over or along, but not against, the exposed edges. Starting at the low point of the roof, set the roll and unroll the roll up to half of the length where possible to assure proper alignment. Torch apply the flame to the surface of the coiled roll until the surface reaches the proper application temperature (330°F to 350°F [166°C to 176°C]). This fully burns off the polyethylene release backing and causes the bitumen on the back of the roll to flow and provide full coverage and adhesion of the membrane to the substrate.

Slowly unroll the torch heated roll while applying sufficient pressure to the roll to adhere the sheet to the underlying surface. Align the next roll along the factory applied lay line at the inside of the 4" (101 mm) selvage and continue application. A 1/8" to 3/8" (3 mm to 10 mm) bleed out of SBS modified bitumen extending beyond the edge of each lap is required. Immediately apply matching granules into this bleed out along all side laps and end laps. Roll side laps and end laps with a steel lap roller and check all laps for proper adhesion.

The torch flame must be moved from side to side to heat the back of the sheet enough to develop a glossy sheen. In addition, the selvage and end lap areas of the previously applied

POWERply® Standard FR HW

APPLICATION CONTINUED

sheet must be torch heated to provide proper adhesion. Heavy smoke from the torched surface indicates the surface is being over-heated.

Embed the granules on POWERply Standard FR HW prior to adhering additional sheeting over it at end laps, base flashings and for patchwork. Heat the granule section and press the granules into the compound using a steel trowel to provide a surface capable of proper adhesion.

Side laps 4" (102 mm) minimum; end laps 6" (152mm) minimum. Offset membrane laps from the ply sheet laps. Stagger end laps at least 36" (914 mm). To assure complete adhesion at lap edges, adhesive should be visible past lap edges. Install flashings as specified.

LIMITATIONS

- Not intended to perform under ponding conditions. Positive drainage required.
- Not to be exposed to solvents, oils, or other contaminants harmful to asphaltic materials.
- Do not use cold process membrane adhesives in contact with the polyethylene backing on the membrane
- Backnail on roofs with slopes 2:12 (2" per foot) (16.6%) or greater.

PHYSICAL PROPERTIES

PROPERTY	TYPICAL VALUE	TEST METHOD
Thickness	0.165 in. (4.2 mm)	ASTM D5147
Tensile strength @ 0°F (-18°C)	120 lbf/in. MD (21kN/m), 100 lbf/in. XMD (17.5kN/m)	ASTM D5147
Elongation at 0°F (-18°C)	4% MD, 4% XMD	ASTM D5147
Tensile Strength @ 77°F (25°C)	70 lbf/in MD (12.3kN/m), 50 lbf/in XMD (8.8 kN/m)	ASTM D5147
Elongation at 77°F (25°C)	4% MD, 4% XMD	ASTM D5147
Tear strength at 77°F (25°C)	100 lbf MD (445N), 90 lbf XMD (400N)	ASTM D5147
Low Temp Flex	-10°F (-23°C)	ASTM D5147
Dimensional Stability	pass	ASTM D5147
Compound Stability @ 215°F (102°C)	pass	ASTM D5147

PRODUCT PRECAUTIONS

Provide written notice to the local fire department in localities where required. Obtain permits for application of roofing by torch where required. A fully charged, 20 lb minimum ABC dry chemical fire extinguisher must be available for each man on the project.

Roofing workers should wear proper protective equipment for torch installations, including long sleeved nonsynthetic shirts, long pants with no cuffs, boots, heat resistant gloves, and a face shield.

Roofing workers must be properly trained in safe application techniques for torch applied roofing, such as provided by the CERTA (Certified Roofing Torch Applicator) Program.

Do not torch onto or near combustible materials or surfaces. Do not torch near or into vents, openings, cracks, or penetrations into the building. Shut off power fans in the torch area. Never leave lighted torches unattended.

A fire watch never shorter than 1 hour after the torch application is required for all torch applications. A longer fire watch may be necessary due to the size or configuration of the building. Use an infra-red heat imaging device to detect hot spots or smoldering materials. If a fire is detected, contact the fire department immediately.

Tremco does not supervise contractors or any other person in the application of heat welded torch applied modified bitumen and assumes no responsibility for fire damage or any other damages.

MAINTENANCE

Your local Tremco Roofing Sales Representative can provide you with effective maintenance procedures which may vary, depending upon specific conditions. Periodic inspections, early repairs and preventative maintenance are all part of a sound roof program.

POWERply® Standard FR HW

GENERAL PRECAUTIONS

Users must read container labels and Safety Data Sheets for health and safety precautions prior to use.

TECHNICAL SUPPORT

Your local Tremco Roofing Sales Representative, working with the Technical Service Staff, can help analyze conditions and needs to develop recommendations for special applications.



Roofing & Building Maintenance

www.tremcoroofing.com

3735 Green Road
Beachwood, Ohio 44122
1.800.852.6013

50 Beth Neelson Drive
Toronto, Ontario M4H 1M6
1.800.668.9879

Tremco Roofing & Building
Maintenance is a part of the Tremco
Construction Products Group

Tremco is a US Registered trademark of Tremco Incorporated.

The information provided on this data page supersedes all previous data concerning this product and its application.

The Statements provided concerning the materials shown are intended solely as a general guide for material usage and are believed to be true and accurate. Since the manner of use is beyond our control, Tremco DOES NOT MAKE NOR DOES IT AUTHORIZE ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PURPOSE, OR ANY OTHER WARRANTY, GUARANTEE OR REPRESENTATION, EXPRESSED OR IMPLIED, CONCERNING THIS MATERIAL EXCEPT THAT IT CONFORMS TO TREMCO'S PRODUCT SAMPLE. Buyer and user accept the product under those conditions and assume the risk of any failure, injury of person or property and loss or liability resulting from the handling, storage or use of the product, whether or not it is handled, stored, used in accordance with directions or specifications. UNDER NO CIRCUMSTANCE SHALL TREMCO BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES ARISING FROM ANY BREACH OF WARRANTY. IN ALL CASES, TREMCO'S LIABILITY IS LIMITED, AT TREMCO'S OPTION, TO THE REPLACEMENT OF GOODS, OR THEIR VALUE, PROVEN TO BE DEFECTIVE IN MANUFACTURING.